
### **Main Line Filter**


## 25A-AFF Series ROHS





<sup>\*3</sup> Assembly of a bracket and 2 mounting screws

#### \*2 When symbol "B" is indicated, a bracket assembly with a part number shown in the left table is shipped together as an accessory, (but not assembled).



#### Bracket Assembly Part Nos.\*3

Applicable model	Part no.
25A-AFF37B	25A-BM56
25A-AFF75B	25A-BM57

<sup>\*3</sup> Assembly of a bracket and 2 mounting screws

- can be selected. The drain cock, N.O. auto drain and drain guide cannot be selected together.
  - \* The 25A- series specifications and dimensions are the same as those of the standard model.

Click here for details.



with a part number shown in the left table is shipped together as an accessory, (but not assembled).


### **Mist Separator**

## 25A-AM Series


Applicable body size

150C 250C 350C 450C 550C

RoHS



#### 25A-AM150C to 25A-AM550C



150C 250C 350C 450C 550C

Symbol Type
Nil Rc
F G
N NPT

Port size

Symbol Size

1/8

1/4

3/8

1/2

3/4

01

02

03

04

06

10

Symbol Description

Nil —

J\*4,\*5 Drain guide 1/4 female threaded

R IN-OUT reversal direction

T With element service indicator

\*5 Drain piping and piping for a stop valve such as ball valve are required.

#### → Auto drain\*4

Symbol	Description
Nil	Drain cock (Without auto drain)
С	N.C. auto drain
D	N.O. auto drain

\*4 Only one drain exhaust method can be selected. The drain cock, N.C. auto drain, N.O. auto drain and drain guide cannot be selected together.

#### Bracket Assembly Part Nos.\*3

Applicable model	Part no.
25A-AM150C	25A-AM-BM101
25A-AM250C	25A-AM-BM102
25A-AM350C	25A-AM-BM103
25A-AM450C	25A-AM-BM104
25A-AM550C	25A-AM-BM105


\*3 Assembly of a bracket and 2 mounting screws

#### Accessory

Symbol	Description
Nil	_
В	Bracket *2

\*2 When symbol "B" is indicated, a bracket assembly with a part number shown in the left table is shipped together as an accessory, (but not assembled).

#### 25A-AM650/850



 Port size ●

 Symbol
 Size
 Applicable body size

 650
 850

 10
 1
 ●
 —

 14
 1 ½
 ●
 ●

 20
 2
 —
 ●

#### **Bracket Assembly Part Nos.\*3**

Applicable model	Part no.
25A-AM650	25A-BM56
25A-AM850	25A-BM57

\*3 Assembly of a bracket and 2 mounting screws

#### Accessory •

Symbol	Description
Nil	_
В	Bracket *1

\*1 When symbol "B" is indicated, a bracket assembly with a part number shown in the left table is shipped together as an accessory, (but not assembled).

#### Option

Symbol	Description
Nil	<del>_</del>
<b>J</b> *4,*5	Drain guide 1/4 female threaded (650 only)
R	IN-OUT reversal direction
Т	With element service indicator

\*5 Drain piping and piping for a stop valve such as ball valve are required.

#### Auto drain\*⁴

Symbol	nbol Description	
Nil	Drain cock (Without auto drain) *2	
D	N.O. auto drain (650 only)	

- \*2 Body size 850 is equipped with a ball valve (Rc 3/8 female threaded).
- \*4 Body size 650: Only one drain exhaust method can be selected. The drain cock, N.O. auto drain and drain guide cannot be selected together.
  - \* The 25A- series specifications and dimensions are the same as those of the standard model.

Click here for details.

ed Air Cylinders Control Valves

y Related ors Products

Air Grippers Actuators

Vacuum Equipment A

r Preparation Equipment

Clean Air Filters

Modular F.R.L./Pressure Control Equipment

S Control Equip

ol Detection t Switches


Fluid Control Equipment


Electric Actuators

### **Micro Mist Separator**

## 25A-AMD Series







Bracket Assembly Part Nos.\*3

Applicable model	Part no.
25A-AMD650	25A-BM56
25A-AMD850	25A-BM57

<sup>\*3</sup> Assembly of a bracket and 2 mounting screws

- ball valve (Rc 3/8 female threaded).
- Body size 650: Only one drain exhaust method can be selected. The drain cock, N.O. auto drain and drain guide cannot be selected together.

<sup>\*</sup> The 25A- series specifications and dimensions are the same as those of the standard model. Click here for details.




a bracket assembly with a part number shown in the left table is shipped together as an accessory, (but not assembled).

## **Micro Mist Separator with Pre-filter**

## 25A-AMH Series






<sup>25</sup>A-AMH550C 25A-AMBM105

\*3 Assembly of a bracket and 2 mounting screws

\*2 When symbol "B" is indicated, a bracket assembly with a part number shown in the left table is shipped together as an accessory, (but not assembled).

#### 25A-AMH650/850



#### Bracket Assembly Part Nos \*3

14

11/2

2

Diacket Assembly Fait Nos.		
Applicable model	Part no.	
25A-AMH650	25A-BM56	
25A-AMH850	25A-BM57	

\*3 Assembly of a bracket and 2 mounting screws

- Symbol Description

  Nil —

  B Bracket \*1

  \*1 When symbol "R" is indicate
  - \*1 When symbol "B" is indicated, a bracket assembly with a part number shown in the left table is shipped together as an accessory, (but not assembled).

Symbol	Description
Nil	Drain cock (Without auto drain) *2
D	N.O. auto drain (650 only)

- \*2 Body size 850 is equipped with a ball valve (Rc 3/8 female threaded).
- \*4 Body size 650: Only one drain exhaust method can be selected. The drain cock, N.O. auto drain and drain guide cannot be selected together.

Air Cylinders Control Valves

Related Products

Air Grippers Actuators

Equipment All

Air Preparation Equipment

Nodular F.R.L.Pressure Clean Control Equipment Air Filters

Control Equipment (

Detection Switches

Fluid Control Equipment

Electric F Actuators


<sup>\*</sup> The 25A- series specifications and dimensions are the same as those of the standard model. Click here for details.

## **Exhaust Cleaner for Clean Room**

## 25A-AMP Series







**06** Rc3/4

#### **Bracket Assembly Part Nos.**\*2

Applicable model		Part no.	
	25A-AMP220	25A-BM66	
	25A-AMP320	25A-BM67	
	25A-AMP420	25A-BM68	

<sup>\*2</sup> Assembly of a bracket and 2 mounting screws


Symbol	Name
Nil	None
В	With bracket*1

- \*1 When symbol "B" is indicated, a bracket assembly with a part number shown in the left table is shipped together as an accessory, (but not assembled).
- \* The 25A- series specifications and dimensions are the same as those of the standard model.

Click here for details.



#### **How to Order**



Series compatible with secondary batteries

- Option/Semi-standard: Select one each for a to c.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
- Example) 25A-AF30-N03B-RZ-A

						0			
		Symbol	Description	Body size					
				20	30	40	50	60	
		Nil	Rc	•	•	•	•	•	
2	Pipe thread type	N	NPT	•	•	•	•	•	
		F	G	•	•	•	•	•	
		+							
		01	1/8	•	_	_	_	_	
		02	1/4	•	•	•	_	_	
A	Port size	03	3/8	_	•	•	_	_	
8	Port Size	04	1/2	_	_	•	_	_	
		06	3/4	_	_	•	•	_	
		10	1	_	_	_	•	•	
		+							
	a Mounting	Nil	Without mounting option		•	•	•		
4	o Nourilling	B*1	With bracket	•	•	•	•	•	
		+							
	ਨੂੰ b Flow direction	Nil	Flow direction: Left to right		•	•	•		
	p Flow direction	R	Flow direction: Right to left	•	•	•	•	•	
6	b Flow direction  c Pressure unit	+							
	c Pressure unit	Nil	Name plate and caution plate for bowl in SI units: MPa	•	•	•	•	•	
	S C Flessure unit	<b>Z</b> *2	Name plate and caution plate for bowl in imperial units: psi, °F	○*2	O*2	O*2	O*2	O*2	

- \*1 A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws.
- \*2 O: For pipe thread type: NPT. This product is for overseas use only according to the New Measurement Law. (The SI unit type is provided for use in Japan.)
  - \* The 25A- series specifications and dimensions are the same as those of the standard model.

Click here for details.

#### Bracket, Bowl Assembly Part Nos. for the 25A- Series

Model Option	25A-AF20-A	25A-AF30-A	25A-AF40-A	25A-AF40-06-A	25A-AF50-A 25A-AF60-A
Bracket assembly*1	25A-AF22P-050AS	25A-AF32P-050AS	25A-AF42P-050AS	25A-AF42P-070AS	25A-AF52P-050AS
Bowl assembly	25A-C2SF-A	25A-C3SF-A		25A-C4SF-A	

<sup>\*1</sup> Assembly of a bracket and 2 mounting screws.

Air Cylinders Control Valves

#### **Mist Separator**


## 25A-AFM20-A to 25A-AFM40-A Micro Mist Separator

### 25A-AFD20-A to 25A-AFD40-A



• 25A-AFD Series Nominal filtration rating: 0.01 μm

#### **How to Order**



Option/Semi-standard: Select one each for a to c.
 Option/Semi-standard symbol: When more than or

 Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order. Example) 25A-AFM30-N03B-RZ-A

						0		
		Symbol	Symbol Description		Body size			
					20	30	40	
			Nil	Rc	•	•	•	
2	Pip	e thread type	N	NPT	•	•	•	
			F	G	•	•	•	
			+					
			01	1/8	•	_	_	
			02	1/4	•	•	•	
8		Port size		3/8	_	•	•	
				1/2	_	_	•	
				3/4	_	_	•	
			+					
4	Option	a Mounting	Nil	Without mounting option	•	•	•	
4	g   g	i Mounting	B*1	With bracket	•	•	•	
			+					
	lard	Flow direction	Nil	Flow direction: Left to right	•	•	•	
	ng L	I low direction	R	Flow direction: Right to left	•	•	•	
6	Semi-standard		+					
	Ë	Pressure unit	Nil	Name plate and caution plate for bowl in SI units: MPa	•	•	•	
	Ser	Fressure unit	<b>Z</b> *2	Name plate and caution plate for bowl in imperial units: psi, °F	O*2	O*2	O*2	

<sup>\*1</sup> A bracket is not assembled and supplied loose at the time of shipment. Including 2 mounting screws.

\* The 25A- series specifications and dimensions are the same as those of the standard model.

Click here for details.

#### Bracket, Bowl Assembly Part Nos. for the 25A- Series

Model Option	25A-AFM20-A 25A-AFD20-A	25A-AFM30-A 25A-AFD30-A	25A-AFM40-A 25A-AFD40-A	25A-AFM40-06-A 25A-AFD40-06-A			
Bracket assembly*1	25A-AF22P-050AS	25A-AF32P-050AS	25A-AF42P-050AS	25A-AF42P-070AS			
Bowl assembly	25A-C2SF-A	25A-C3SF-A	25A-C4SF-A				

<sup>\*1</sup> Assembly of a bracket and 2 mounting screws.



<sup>\*2</sup> O: For pipe thread type: NPT. This product is for overseas use only according to the New Measurement Law. (The SI unit type is provided for use in Japan.)


## 25A-AR20-B to 25A-AR60-B

**Regulator with Backflow Function** 

## 25A-AR20K-B to 25A-AR60K-B



#### **How to Order**



- Option/Semi-standard: Select one each for a to f.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.
   Example) 25A-AR30K-03B-1NR-B

S			Symbol	Description				Body	size		
						20	25	30	40	50	60
	With back	flow	Nil	Without backflow function		•	•	•	•	•	•
	function	n [	K	With backflow function			•				
			+								
			Nil	Rc		•	•		•	•	
	Pipe thread	l type	N	NPT			•				
			F	G							
			+								
			01	1/8		•		<u> </u>	_	_	_
			02	1/4		•	•	•	•	_	_
	Dort -!-	_	03	3/8		_	•	•	•	_	_
	Port siz	е	04	1/2		—	_	_	•	_	_
			06	3/4		_	_	_	•	•	_
			10	1		_	_	_		•	
			+								
*1			Nil	Without mounting option		•	•				
Option *	a Mounting	<b>B</b> *2	With bracket		Ŏ	Ŏ	Ŏ	•	•		
ြင		a  g	Н	With set nut (For panel fitting)		•	•		•	_	_
			+								
			Nil	0.05 to 0.85 MPa setting			•				
	b Set pr	ressure	1*3	0.02 to 0.2 MPa setting		•	•				
			+								
	Fyh	naust	Nil	Relieving type							4
ō	c   mech	nanism	N	Non-relieving type			•	•		•	
Semi-standard			+			_	_				
anc			Nil	Flow direction: Left to right		•					_
ste	d Flow d	lirection	R	Flow direction: Earl to right  Flow direction: Right to left							
=			+	1 low direction. Hight to left							
Ser			Nil	Downward							_
(0)	e Kr	nob	Y	Upward			_				
			-	Upwaiu		•					
			+ N::	Name whate in Oliveite, MDs							_
	f Pressi	ure unit	Nil	Name plate in SI units: MPa		<b>O</b> *4		0 *4	O *4	O#4	
			<b>7</b> *4	Name plate in imperial units: psi	11 (	O*4	O*4	O*4	O*4	O*4	$\bigcirc$

- \*1 Option "B", "H" are not assembled and supplied loose at the time of shipment.
- \*2 Assembly of a bracket and set nuts (25A-AR20(K) to 25A-AR40(K)). Including 2 mounting screws for the 25A-AR50(K) and 25A-AR60(K).
- \*3 Pressure can be set at the upper limit of the specification or more, however, be sure to set the pressure within specification.
- \*4 O: For pipe thread type: NPT. This product is for overseas use only according to the New Measurement Law. (The SI unit type is provided for use in Japan.)

\* The 25A- series specifications and dimensions are the same as those of the standard model.

Click here for details.

#### Bracket, Set Nut Part Nos. for the 25A- Series

Model Option	25A-AR20(K)-B	25A-AR25(K)-B	25A-AR30(K)-B	25A-AR40(K)-B	25A-AR50(K)-B 25A-AR60(K)-B
Bracket assembly*1	25A-AR23P-270AS	25A-AR28P-270AS	25A-AR33P-270AS	25A-AR43P-270AS	25A-AR52P-270AS*2
Set nut	AR23P-260S	AR28P-260S	AR33P-260S	AR43P-260S	<u>_</u> *3

- \*1 Assembly of a bracket and set nuts.
- \*2 Assembly of a bracket and 2 mounting screws.
- \*3 Please consult with SMC regarding the set nuts for the 25A-AR50(K) and 25A-AR60(K).



Directional Control Valves

Air Cylinders

Related Products

Rotary Actuators

Vacuum Equipment Air Grippers

Air Preparation Equipment E

Clean Air Filters

### **Filter Regulator**


### 25A-AW20-B to 25A-AW60-B

**Filter Regulator with Backflow Function** 

## 25A-AW20K-B to 25A-AW60K-B



#### How to Order



Series compatible with secondary batteries

- Option/Semi-standard: Select one each for a to e.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

Example) 25A-AW30K-03B-1N-B

				0	Description				
				Symbol	Description		Body		
						20	30	40	60
	/ / /:±	مطط	ackflow function	Nil	Without backflow function	•	•	•	•
2	VVII	n Da	acknow function	K	With backflow function	•	•	•	•
				+					
				Nil	Rc			•	•
<b>3</b>	F	Pipe	thread type	N	NPT	•		•	•
				F	G	•		•	•
				+					
				01	1/8	•	_	_	_
				02	1/4	•		•	_
4			Port size	03	3/8			•	_
				04	1/2		_	•	_
				06	3/4		_	•	
				10	1	_	_	_	•
				+				T	
	*1			Nil	Without mounting option	•	•	•	•
6	Option	а	Mounting	<b>B</b> *2	With bracket	•	•	•	•
	Ö			Н	With set nut (For panel fitting)				_
				+				Т	
		b	Set pressure	Nil	0.05 to 0.85 MPa setting	•	•	•	•
			Cot procedio	<b>1</b> *3	0.02 to 0.2 MPa setting				
	-			+	11				
	arc	С	Exhaust	Nil	Relieving type		•	•	•
	anc		mechanism	N	Non-relieving type				
6	Semi-standard			+					
	Ē	d	Flow direction	Nil	Flow direction: Left to right	•	•	•	•
	Se			R	Flow direction: Right to left				
				+					
		е	Pressure unit	Nil	Name plate and caution plate for bowl in SI units: MPa	•	0	0	0
			- 15000.10 drille	<b>Z</b> *4	Name plate and caution plate for bowl in imperial units: psi, °F	○*4	O*4	O*4	O*4

- \*1 Option "B", "H" are not assembled and supplied loose at the time of shipment.
- \*2 Assembly of a bracket and set nuts (25A-AW20(K) to 25A-AW40(K)). Including 2 mounting screws for the 25A-AW60(K).
- \*3 Pressure can be set at the upper limit of the specification or more, however, be sure to set the pressure within specification.
- \*4 : For pipe thread type: NPT. This product is for overseas use only according to the New Measurement Law. (The SI unit type is provided for use in Japan.)
  - \* The 25A- series specifications and dimensions are the same as those of the standard model.

Click here for details.


#### Bracket, Set Nut, Bowl Assembly Part Nos. for the 25A- Series

Model	25A-AW20(K)-B	25A-AW30(K)-B	25A-AW40(K)-B	25A-AW60(K)-B			
Bracket assembly*1	25A-AW23P-270AS	25A-AR33P-270AS	25A-AR43P-270AS	25A-AW62P-270AS*2			
Set nut	AR23P-260S	AR33P-260S	AR43P-260S	*3			
Bowl assembly	25A-C2SF-A	25A-C3SF-A	25A-C	C4SF-A			

<sup>\*1</sup> Assembly of a bracket and set nuts.
\*2 Assembly of a bracket and 2 mounting screws.
\*3 Please consult with SMC regarding the set nuts for the 25A-AW60(K).

## **Precision Regulator** 25A-IR1000/2000/3000-A Series

#### How to Order





- Option/Semi-standard: Select one each for a, b, and c.
- Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.

				0	Paradatas		0	
				Symbol	Description	Body size		
						1	2	3
				0	0.005 to 0.2 MPa	•	•	_
2	١	Sat ni	ressure range		0.01 to 0.2 MPa		_	•
9		et þi	lessure range	1	0.01 to 0.4 MPa	•	•	•
				2	0.01 to 0.8 MPa	•	•	•
				+				
				0	Bottom exhaust	•	•	•
8		Exha	aust direction	1	Front exhaust	_	_	•
				2	Rear exhaust	_	_	•
				+			_	
				Nil	Rc	•	•	•
4		Pipe thread type		N	NPT	•	•	•
				F	G	•	•	•
				+			1	
				01	1/8	•	_	_
6		1	Port size	02	1/4		•	•
•			0.1.0.20	03	3/8	_	_	•
			04	1/2		_	•	
				+			1	
	*1			Nil	Without mounting option	•	•	•
6	Option	a	Mounting	<b>B</b> *2	With bracket	•	•	•
				Н	With hexagon panel nut (for panel mount)	•	•	•
				+			•	
	D D	h	Flour direction	Nil	Flow direction: Left to right	•	•	•
	g	nda <sub>1</sub>	Flow direction	R	Flow direction: Right to left	•	•	•
7	Semi-standard			+				
	🛓	آ ا	Knob	Nil	Upward	•	•	•
	Ser	KIIOD	V	Downward	•	•	•	

- Options are shipped together with the product, but not assembled. B and H cannot be selected at the same time. The current bracket cannot be used for this product.
- \*2 Assembly of a bracket and set nuts

Air Cylinders Control Valves

Related Products

Rotary Actuators


Air Grippers Vacuum Equipment

Detection Switches

Electric Fluid Control Actuators Equipment



# Electro-Pneumatic Regulator 25A-ITV1000/2000/3000 Series



- \* Since the lead wires and electrical circuits are used, this product is not completely copper-free. Only the wetted parts are copper-free.
- Copper and zinc materials are used for solenoid valve coils, connector pins, and lead wire substrate.
- \* The 25A- series specifications and dimensions are the same as those of the standard model.

