
### **Mechanically Jointed Rodless Cylinder Basic Type**

# 25A-MY1B Series

Ø16, Ø20, Ø25, Ø32, Ø40, Ø50, Ø63



- Long stroke can be ordered the same as the standard stroke. 25A-MY1B20-3000L-M9BW
- Please be advised that with a stroke of 49 mm or less, there are cases where auto switch mounting is not possible, and the performance of the air cushion may decline.


#### For ø16 to ø40


### Stroke adjustment unit symbol

_												
						Right si	de stroke	adjustn	nent unit			
			Without	A: With adjustment bolt			L: With lov + Adjustm	v load shoc ent bolt	k absorber	H: With hig + Adjustme	h load shoc ent bolt	k absorber
			unit		With short spacer	With long spacer		With short spacer	With long spacer		With short spacer	With long spacer
::	Without unit		Nil	SA	SA6	SA7	SL	SL6	SL7	SH	SH6	SH7
	A: With adjustment bolt		AS	Α	AA6	AA7	AL	AL6	AL7	AH	AH6	AH7
5	L: With low lo	With short spacer	A6S	A6A	A6	A6A7	A6L	A6L6	A6L7	A6H	A6H6	A6H7
4		With long spacer	A7S	A7A	A7A6	<b>A</b> 7	A7L	A7L6	A7L7	A7H	A7H6	A7H7
3		oad shock absorber +	LS	LA	LA6	LA7	L	LL6	LL7	LH	LH6	LH7
3	Adjustment	With short spacer	L6S	L6A	L6A6	L6A7	L6L	L6	L6L7	L6H	L6H6	L6H7
ì	bolt	With long spacer	L7S	L7A	L7A6	L7A7	L7L	L7L6	L7	L7H	L7H6	L7H7
eft side	H: With high	load shock absorber +	HS	HA	HA6	HA7	HL	HL6	HL7	Н	HH6	HH7
		With short spacer	H6S	H6A	H6A6	H6A7	H6L	H6L6	H6L7	Н6Н	H6	Н6Н7
-	bolt	With long spacer	H7S	H7A	H7A6	H7A7	H7L	H7L6	H7L7	H7H	H7H6	H7

- Spacers are used to fix the stroke adjustment unit at an intermediate stroke position.
- The 25A-MY1B50 and 63 are not available with the stroke adjustment unit.
- \* The stroke adjustment unit H unit is not available for the 25A-MY1B16.

#### Stroke adjustment unit mounting diagram






The 25A- series specifications and dimensions are the same Click here for details. as those of the standard model.



# Mechanically Jointed Rodless Cylinder Slide Bearing Guide Type 25A-MY1M Series

Ø16, Ø20, Ø25, Ø32, Ø40, Ø50, Ø63



Cylinder stroke [mm]

В	Sore size	Standard stroke*	Long stroke	Maximum manufacturable stroke
	16	100, 200, 300, 400, 500, 600, 700, 800, 900, 1000, 1200, 1400 1600, 1800, 2000	Strokes of 2001 to 3000 mm (1 mm increments) exceeding the standard stroke	3000
3	20, 25 32, 40 50, 63	The stroke can be manufactured in 1 mm increments from 1 mm stroke.	Strokes of 2001 to 5000 mm (1 mm increments) exceeding the standard stroke	5000

### Ordering example


- \* Long stroke can be ordered the same as the standard stroke. 25A-MY1M20-3000L-M9BW
- \* Please be advised that with a stroke of 49 mm or less, there are cases where auto switch mounting is not possible, and the performance of the air cushion may decline.


#### Stroke adjustment unit symbol

				Stroke adjustment unit symbols										
				Right side stroke adjustment unit										
			Without	A: With		ent bolt		ow load sh + Adjustr			nigh load s + Adjustr			
		unit		With short spacer	With long spacer		With short spacer	With long spacer		With short spacer	With long spacer			
ij	Wit	hout unit	Nil	SA	SA6	SA7	SL	SL6	SL7	SH	SH6	SH7		
ustment unit	A: With adjustment bolt		AS	Α	AA6	AA7	AL	AL6	AL7	AH	AH6	AH7		
me		With short spacer	A6S	A6A	<b>A6</b>	A6A7	A6L	A6L6	A6L7	A6H	A6H6	A6H7		
ust		With long spacer	A7S	A7A	A7A6	<b>A</b> 7	A7L	A7L6	A7L7	A7H	A7H6	A7H7		
adj		oad shock absorber +	LS	LA	LA6	LA7	L	LL6	LL7	LH	LH6	LH7		
stroke	Adjustment bolt	With short spacer	L6S	L6A	L6A6	L6A7	L6L	L6	L6L7	L6H	L6H6	L6H7		
stro	DOIL	With long spacer	L7S	L7A	L7A6	L7A7	L7L	L7L6	L7	L7H	L7H6	L7H7		
side		load shock absorber +	HS	HA	HA6	HA7	HL	HL6	HL7	Н	HH6	HH7		
	Adjustment bolt	With short spacer	H6S	H6A	H6A6	H6A7	H6L	H6L6	H6L7	Н6Н	H6	H6H7		
Left	DOIL	With long spacer	H7S	H7A	H7A6	H7A7	H7L	H7L6	H7L7	H7H	H7H6	H7		

- \* Spacers are used to fix the stroke adjustment unit at an intermediate stroke position.
- Stroke adjustment unit H is not available for 25A-MY1M16.
- \* The 25A- series specifications and dimensions are the same as those of the standard model.

### Stroke adjustment unit mounting diagram










### **Mechanically Jointed Rodless Cylinder** Cam Follower Guide Type

# 25A-MY1C Series

Ø16, Ø20, Ø25, Ø32, Ø40, Ø50, Ø63



								Stro	ke adju	stment	unit sy	/mboi ●
						Right sid	de stroke	adjustn	nent unit			
			Without	A: With adjustment bolt			L: With low load shock absorber + Adjustment bolt			H: With hig + Adjustme	h load shoc ent bolt	k absorber
			unit		With short spacer	With long spacer		With short spacer	With long spacer		With short spacer	With long spacer
:	Wi	thout unit	Nil	SA	SA6	SA7	SL	SL6	SL7	SH	SH6	SH7
				Α	AA6	AA7	AL	AL6	AL7	AH	AH6	AH7
3	A: With a	With short spacer	A6S	A6A	A6	A6A7	A6L	A6L6	A6L7	A6H	A6H6	A6H7
3		With long spacer	A7S	A7A	A7A6	A7	A7L	A7L6	A7L7	A7H	A7H6	A7H7
3	_	oad shock absorber +	LS	LA	LA6	LA7	L	LL6	LL7	LH	LH6	LH7
3	Adjustment	With short spacer	L6S	L6A	L6A6	L6A7	L6L	L6	L6L7	L6H	L6H6	L6H7
į	bolt	With long spacer	L7S	L7A	L7A6	L7A7	L7L	L7L6	L7	L7H	L7H6	L7H7
9 2 1	H: With high	load shock absorber +	HS	HA	HA6	HA7	HL	HL6	HL7	Н	HH6	HH7
		With short spacer	H6S	H6A	H6A6	H6A7	H6L	H6L6	H6L7	Н6Н	H6	Н6Н7
Left	B  bolt	With long spacer	H7S	H7A	H7A6	H7A7	H7L	H7L6	H7L7	H7H	H7H6	H7

Spacers are used to fix the stroke adjustment unit at an intermediate stroke position.

Air Cylinders

Control Valves

Related Products

Rotary Actuators

Air Grippers Equipment

Air Preparation

Modular F.R.L./Pressure Control Equipment

Control Equipment

Intermediate fixing spacer

Right side

Stroke adjustment unit

Left side H unit

Short spacer

Spacer length

**Example of H6H7 attachment** 

H unit

Long space

Detection Switches

Fluid Control Equipment

Electric Actuators

Switches

100 A


Stroke adjustment unit H is not available for 25A-MY1C16.

<sup>\*</sup> The 25A- series specifications and dimensions are the same as those of the standard model. Click here for details.

### **Mechanically Jointed Rodless Cylinder Linear Guide Type**


## 25A-MY1H Series

Ø16, Ø20, Ø25, Ø32, Ø40





### Stroke adjustment unit symbol • Stroke adjustment unit

			or one adjustment unit symbol										
				Right side stroke adjustment unit									
			Without	A: With	adjustm	ent bolt	L: With lov + Adjustm	v load shoc ent bolt	k absorber	H: With hig + Adjustm	gh load shoc ent bolt	k absorber	
			unit		With short spacer	With long spacer		With short spacer	With long spacer		With short spacer	With long spacer	
Ħ	≝ Without unit		Nil	SA	SA6	SA7	SL	SL6	SL7	SH	SH6	SH7	
ustment unit	A: With a	djustment bolt	AS	Α	AA6	AA7	AL	AL6	AL7	AH	AH6	AH7	
ner		With short spacer	A6S	A6A	A6	A6A7	A6L	A6L6	A6L7	A6H	A6H6	A6H7	
nsti		With long spacer	A7S	A7A	A7A6	<b>A</b> 7	A7L	A7L6	A7L7	A7H	A7H6	A7H7	
adji	L: With low lo	oad shock absorber +	LS	LA	LA6	LA7	L	LL6	LL7	LH	LH6	LH7	
troke	Adjustment	With short spacer	L6S	L6A	L6A6	L6A7	L6L	L6	L6L7	L6H	L6H6	L6H7	
stro	bolt	With long spacer	L7S	L7A	L7A6	L7A7	L7L	L7L6	L7	L7H	L7H6	L7H7	
g		H: With high load shock absorber +		HA	HA6	HA7	HL	HL6	HL7	Н	HH6	HH7	
ဟ	Adjustment	With short spacer	H6S	H6A	H6A6	H6A7	H6L	H6L6	H6L7	Н6Н	H6	Н6Н7	
Left	bolt	With long spacer	H7S	H7A	H7A6	H7A7	H7L	H7L6	H7L7	H7H	H7H6	H7	



The 25A- series specifications and dimensions are the same as those of the standard model.






# Mechanically Jointed Rodless Cylinder Cam Follower Guide Type

# 25A-MY2C Series

ø16, ø25, ø40





### Cylinder stroke [mm]

Bore size [mm]	Standard stroke [mm]*1	Max. manufacturable stroke [mm]
16	100, 200, 300, 400, 500, 600, 700, 800,	3000
25, 40	900, 1000, 1200, 1400, 1600, 1800, 2000	5000

- \*1 Strokes are manufacturable in 1 mm increments, up to the maximum stroke.

  However, please be advised that with stroke 49 or less, there are cases where auto switch mounting is not possible and the performance of the air cushion may decline.
- \* Long stroke can be ordered the same as the standard stroke. MY2C25-3000L-M9BW

### Stroke adjustment unit symbol

			Right side stroke adjustment unit							
			Without	L: With absorbe	low load	shock	H: With absorbe	high load	l shock	
			unit		With short spacer	With long spacer		With short spacer	With long spacer	
	Without unit			SL	SL6	SL7	SH	SH6	SH7	
ş ş		w load shock	LS	L	LL6	LL7	LH	LH6	LH7	
stro	absorber	With short spacer	L6S	L6L	L6	L6L7	L6H	L6H6	L6H7	
Left side stroke		With long spacer	L7S	L7L	L7L6	L7	L7H	L7H6	L7H7	
t Si	H: With hi	gh load shock	HS	HL	HL6	HL7	Н	HH6	HH7	
Lef	absorber	With short spacer	H6S	H6L	H6L6	H6L7	Н6Н	H6	Н6Н7	
		With long spacer	H7S	H7L	H7L6	H7L7	Н7Н	H7H6	H7	


\* Spacers are used to fix the stroke adjustment unit at an intermediate stroke position.

#### Stroke adjustment unit mounting diagram


Without auto switch (Built-in magnet)

Refer to page 205 for the

applicable auto switch model.



#### Example of L6L7 attachment



\* The 25A- series specifications and dimensions are the same as those of the standard model. Click here for details.



Directional Control Valves

Air Cylinders

Related Products

Rotary Actuators

Equipment Air Grippers

Air Preparation Equipment

> Clean Air Filters

Modular F.R.L./Pressure Control Equipment

Detection Fittings/Flow Switches Control Equipment

ontrol Dete

Fluid Control

Electric Actuators

Auto Switches


101-1 A



### **Mechanically Jointed Rodless Cylinder** Linear Guide Type

# 25A-MY2H/HT Series

ø16, ø25, ø40



- 25, 40 1500 \*1 Strokes are manufacturable in 1 mm increments, up to the maximum stroke.
- Intermediate stroke can be ordered the same as the standard stroke.

#### MY2H10-60-M9BW


Long stroke can be ordered the same as the standard stroke. MY2H20-800L-M9BW


### Stroke adjustment unit symbol

			Right side stroke adjustment unit								
			Without	L: With labsorbe	low load s	shock	H: With high load shock absorber				
			unit		With short spacer	With long spacer		With short spacer	With long spacer		
	Wit	thout unit	Nil	SL	SL6	SL7	SH	SH6	SH7		
활별		w load shock	LS	L	LL6	LL7	LH	LH6	LH7		
stroke nt unit	absorber	With short spacer	L6S	L6L	L6	L6L7	L6H	L6H6	L6H7		
a ge		With long spacer	L7S	L7L	L7L6	L7	L7H	L7H6	L7H7		
- 3	H: With high load shock absorber With short spacer		HS	HL	HL6	HL7	Н	HH6	HH7		
Lef			H6S	H6L	H6L6	H6L7	Н6Н	H6	H6H7		
		With long spacer	H7S	H7L	H7L6	H7L7	H7H	H7H6	H7		

Spacers are used to fix the stroke adjustment unit at an intermediate stroke position.

### Stroke adjustment unit mounting diagram





\* The 25A- series specifications and dimensions are the same as those of the standard model. Click here for details.



Directional Control Valves

Air Cylinders

Related Products

Rotary Actuators Air Grippers

Equipment

Air Preparation

Modular F.R.L./Pressure Control Equipment

Control Equipment

**Detection** Switches

Fluid Control Equipment


Actuators Electric

Switches

### Mechanically Jointed Rodless Cylinder/Basic Type

# 25A-MY3A/3B Series


Ø16, Ø20, Ø25, Ø32, Ø40, Ø50, Ø63



#### Stroke adjustment unit symbol

			Right side stroke adjustment unit								
				L: With lov + Adjustme	v load shock ent bolt	c absorber	H: With high load shock at + Adjustment bolt		k absorber		
			unit		With short spacer	With long spacer		With short spacer	With long spacer		
ω+-	Without u	Nil	SL	SL6	SL7	SH	SH6	SH7			
돌	L: With low load shock absorber +		LS	L	LL6	LL7	LH	LH6	LH7		
nt t	Adjustment	With short spacer	L6S	L6L	L6	L6L7	L6H	L6H6	L6H7		
side stroke stment unit	bolt	With long spacer	L7S	L7L	L7L6	L7	L7H	L7H6	L7H7		
sist	Adjustment	oad shock absorber +	HS	HL	HL6	HL7	Н	HH6	HH7		
Left adjus		With short spacer	H6S	H6L	H6L6	H6L7	Н6Н	H6	H6H7		
_ · ·	bolt	With long spacer	H7S	H7L	H7L6	H7L7	H7H	H7H6	H7		

<sup>\*</sup> Spacers are used to fix the stroke adjustment unit at an intermediate stroke position.



Stroke adjustment unit mounting diagram

Stroke adjustment

fixing spacer

Example of L7L6 attachment

TI 054

<sup>\*</sup> The 25A- series specifications and dimensions are the same as those of the standard model. Click here for details.

### **Mechanically Jointed Rodless Cylinder Slide Bearing Guide Type**

# 25A-MY3M Series

Ø16, Ø25, Ø40, Ø63

**How to Order** 25A-MY3 M 16 300 M9BW Series compatible Number of auto switches with secondary 2 batteries S 1 n n Slide bearing guide type Auto switch Cylinder bore size Without auto switch (Built-in magnet) 16 16 mm Refer to page 205 for auto switch model 25 25 mm numbers. 40 40 mm 63 63 mm Port thread type Symbol Bore size Type ø16 M5 Nil Rc ΤN NPT ø25, ø40, ø63 TF G Cylinder stroke [mm] Maximum Bore size Standard stroke\* Long stroke manufacturable stroke 100, 200, 300, 400, 500, 600 700, 800, 900, 1000, 1200 Strokes of 2001 to 3000 mm 16, 25 1400, 1600, 1800, 2000 (1 mm increments) exceeding 3000 40,63 \* The stroke can be the standard stroke manufactured in 1 mm increments from 1 mm stroke. Ordering example


- Long stroke can be ordered the same as the standard stroke. 25A-MY3M25-3000L-M9BW
- Please be advised that with a stroke of 49 mm or less, there are cases where auto switch mounting is not possible, and the performance of the air cushion may decline.

#### Stroke adjustment unit symbol

				Right side stroke adjustment unit								
				L: With low + Adjustme		k absorber	H: With high load shock abs + Adjustment bolt		k absorber			
			unit			With long spacer			With long spacer			
	Without u	ınit	Nil	SL	SL6	SL7	SH	SH6	SH7			
i š	L: With low load shock absorber +		LS	L	LL6	LL7	LH	LH6	LH7			
stroke int unit	Adjustment	With short spacer	L6S	L6L	L6	L6L7	L6H	L6H6	L6H7			
a e	bolt	With long spacer	L7S	L7L	L7L6	L7	L7H	L7H6	L7H7			
t si	H: With high I	oad shock absorber +	HS	HL	HL6	HL7	Н	HH6	HH7			
Left side s adjustmer	Adjustment bolt	With short spacer	H6S	H6L	H6L6	H6L7	Н6Н	H6	H6H7			
	DOIL	With long spacer	H7S	H7L	H7L6	H7L7	H7H	H7H6	H7			

\* Spacers are used to fix the stroke adjustment unit at an intermediate stroke position.

#### Stroke adjustment unit mounting diagram



\* The 25A- series specifications and dimensions are the same as those of the standard model.

Click here for details.

Air Cylinders Control Valves

Related Products

Rotary Actuators

Air Grippers Equipment

Air Preparation

Modular F.R.L./Pressure

Control Equipment

Detection Switches


Fluid Control Equipment

Electric Actuators

Switches

# Magnetically Coupled Rodless Cylinder/Basic Type 25A-CY3B Series

Ø6, Ø10, Ø15, Ø20, Ø25, Ø32, Ø40, Ø50, Ø63



	<b></b>	aara otroko [iiiii] •
Bore size	Standard stroke	Max. manufacturable stroke
6	50, 100, 150, 200	300
10	50, 100, 150, 200, 250, 300	500
15	50, 100, 150, 200, 250, 300, 350 400, 450, 500	1000
20	100 150 000 050 000 050	1500
25	100, 150, 200, 250, 300, 350 400, 450, 500, 600, 700, 800	
32	400, 400, 300, 600, 700, 600	2000
40, 50, 63	100, 150, 200, 250, 300, 350, 400 450, 500, 600, 700, 800, 900, 1000	2000

- Please contact SMC if the maximum stroke is exceeded.
- \* The longer the stroke, the larger the amount of deflection in a cylinder tube. Pay attention to the mounting bracket and clearance value.
- \* Intermediate stroke is available in 1 mm increments.

Click here for details.




<sup>\*</sup> The 25A- series specifications and dimensions are the same as those of the standard model.

### Magnetically Coupled Rodless Cylinder/Direct Mount Type

# 25A-CY3R Series

Ø6, Ø10, Ø15, Ø20, Ø25, Ø32, Ø40, Ø50, Ø63



### **♦**Cylinder stroke [mm]

Bore size	Standard stroke	Max. stroke without switch	Max. stroke with switch
6	50, 100, 150, 200	300	300
10	50, 100, 150, 200, 250, 300	500	500
15	50, 100, 150, 200, 250, 300 350, 400, 450, 500	1000	750
20	100 150 000 050 000 050	1500	1000
25	100, 150, 200, 250, 300, 350 400, 450, 500, 600, 700, 800	1500	1200
32	400, 400, 000, 000, 700, 000		
40, 50, 63	100, 150, 200, 250, 300, 350 400, 450, 500, 600, 700, 800 900, 1000	2000	1500

- \* The longer the stroke, the larger the amount of deflection in a cylinder tube. Pay attention to the mounting bracket and clearance value.
- \* Intermediate stroke is available in 1 mm increments.

Air Cylinders Control Valves

Related Products

Rotary Actuators

Vacuum Equipment Air Grippers

Air Preparation Equipment

> Clean Air Filters

Modular F.R.L./Pressure Control Equipment

Fittings/Flow
S Control Equipment

rol Detection nt Switches

Fluid Control


Electric Actuators

Auto Switches



<sup>\*</sup> The 25A- series specifications and dimensions are the same as those of the standard model.

# Compact Slide 25A-INXH Series Ø6, Ø10, Ø16, Ø20



<sup>\*</sup> The 25A- series specifications and dimensions are the same as those of the standard model.


### Air Slide Table

# 25A-MXS Series

Ø6, Ø8, Ø12, Ø16, Ø20, Ø25

### **How to Order**





### Port thread type

Nil	M thread	ø6 to ø16		
IVII	Rc			
TN	NPT	ø20, ø25		
TF	G			

### Symmetric type

Nil	Standard type
L	Symmetric type

### **♦** Bore size (Standard stroke [mm])

6	10, 20, 30, 40, 50
8	10, 20, 30, 40, 50, 75
12	10, 20, 30, 40, 50, 75, 100
16	10, 20, 30, 40, 50, 75, 100, 125
20	10, 20, 30, 40, 50, 75, 100, 125, 150
25	10, 20, 30, 40, 50, 75, 100, 125, 150

### Number of auto

SWITCHES					
Nil	2				
S	1				
n	n				

#### Auto switch

Nil	Without auto switch			
IVII	(Built-in magnet)			

Refer to page 207 for auto switch model numbers.

### Adjuster option

	•
Nil	Without adjuster
AS	Adjuster on extension end
AT	Adjuster on retraction end
Α	Adjuster on both ends
BS	Absorber on extension end
BT	Absorber on retraction end
В	Absorber on both ends
ASBT	Adjuster on extension end + Absorber on retraction end
BSAT	Absorber on extension end + Adjuster on retraction end

- \* With shock absorber is not available in the 25A-MXS6 series.
- When the adjuster option with shock absorber is used, metal-to-metal collisions occur, and may generate dust particles.

### **Corrosion Resistant Air Slide Table**

(Made to order: 25A-MXS□-X1949)

The material of the head cap part has been changed to a highly corrosion-resistant material.

Please contact your local sales representative for more details

After change Before change Head cap Aluminum Synthetic resin


\* The 25A- series specifications and dimensions are the same as those of the standard model.

# Air Slide Table Double-ported Type



Ø6, Ø8, Ø12, Ø16, Ø20, Ø25

**How to Order** 





Bore	Body option: Double-ported type	3 Standard stroke [mm]		
size	A			
6	Port Switch mounting grove Switch mounting grove	10, 20, 30, 40, 50		
8		10, 20, 30, 40, 50, 75		
12		10, 20, 30, 40, 50, 75, 100		
16	Port Port Switch mounting groove Switch mounting groove	10, 20, 30, 40, 50, 75, 100, 125		
20		10, 20, 30, 40, 50, 75, 100, 125, 150		
25		10, 20, 30, 40, 50, 75, 100, 125, 150*		

 The operating speed range of the stroke marked with an asterisk (\*) is 50 to 300 mm/s. (Without stroke adjuster)

### 5 Functional options

	•	
Symbol	Functional option	
Nil	Without functional option	
1 With buffer		
2	With end lock	
3	Axial piping	
4 With buffer, end lock		
5 With buffer, axial piping		

Number of auto switches

Nil	2
S	1
n	n

### 6 Auto switch

Nil Without auto switch (Built-in magnet)


 For applicable auto switches, refer to page 207.

### 4 Adjuster options/Functional option combinations

					Adjuster mounting Functional option combination								
				posit	ion*1	Nil	1	2	3	4	5		
Symbol		Adjuster type* <sup>6</sup>				Retraction stroke end	Without functional option	*2*7 With buffer	With end lock	Axial piping	With buffer,	*2*5*7 With Buffer, axial piping	l
Z	W	ithout adjuste	r				0	0	0	0	0	0	
ZA					•	•	0	×	×	0	×	×	
ZB	Me	etal stopper v	vith	bumper	•		0	×	0	0	×	×	Ì
ZC						•	0	×	×	0	×	×	
ZD					•	•	0	×	×	0	×	×	l
ZE	Rι	ubber stopper	•		•		0	0	0	0	0	0	
ZF						•	0	×	×	0	×	×	
ZG						•	0	×	×	0	×	×	
ZH	Sr	nock absorbe	r/R	J			0	×	0	0	×	×	
ZJ						•	0	×	×	0	×	×	
ZK						•	0	×	×	0	×	×	
ZL	Me	etal stopper					0	0	0	0	0	0	
ZM						•	0	×	×	0	×	×	
ZN				Without adjuster	] /	1	0	○*4	×	0	×	○*4	
ZP	Q.	norter total		Rubber stopper	] /	•	0	×	×	0	×	×	
ZQ	_	ngth type*3		Shock absorber/RJ	] /	•	0	×	×	0	×	×	
ZS	iei	igiii type · ·	ē	Metal stopper with bumper	] /	•	0	×	×	0	×	×	
ZT			adjuster	Metal stopper	<u>/</u>	•	0	×	×	0	×	×	
ZBF	<u>_</u>	Metal		Rubber stopper	•	•	0	×	×	0	×	×	
ZBJ	ste	stopper with	end	Shock absorber/RJ	•	•	0	×	×	0	×	×	
ZBM	adjuster	bumper		Metal stopper	•	•	0	×	×	0	×	×	
ZEC		Rubber	stroke	Metal stopper with bumper	•	•	0	×	×	0	×	×	
ZEJ	eu	Rubber stopper	st	Shock absorber/RJ	•	•	0	×	×	0	×	×	
ZEM	ô	зторрег	5	Metal stopper	•	•	0	×	×	0	×	×	
ZHC	tro	Shock	etraction	Metal stopper with bumper	•	•	0	×	×	0	×	×	
ZHF			ita 	Rubber stopper	•	•	0	×	×	0	×	×	
ZHM	ši	absolbei/NJ	18	Metal stopper	•	•	0	×	×	0	×	×	
ZLC	Sue	Metal		Metal stopper with bumper	•	•	0	×	×	0	×	×	
ZLF	Extension	stopper		Rubber stopper	•	•	0	×	×	0	×	×	
ZLJ	Ш	stopper		Shock absorber/RJ	•	•	0	×	×	0	×	×	

- Shipped together with the product, but not assembled Without any symbol for the adjuster mounting position: The adjuster can be mounted afterward.
- For the buffer mechanism, the buffer stroke will be shorter for the stroke that is adjusted by the extension stroke end adjuster.
- \*3 Extension stroke end adjuster mounting holes have been removed to reduce the total length of the table.
- \*4 The shorter total length type can be used, but a retraction stroke end adjuster cannot be mounted afterward.
- \*5 There is no piping port on the side surface of the product.
- \*6 The metal stopper with bumper option is not available for ø6.
- \*7 As there is no magnet in the buffer mechanism, auto switches cannot be used on the buffer part.

### **Adjuster Mounting Position**



- \* When the shock absorber, metal stopper with bumper, or adjuster option with metal stopper is used, metal-to-metal collisions occur, and may generate dust particles.
- When the buffer mechanism or the end lock mechanism functional options are used, dust particles may be generated by the buffer part as well as the end lock part.
   The 25A- series specifications and dimensions are the same as those of the standard model.

  Click here for details.




### **Air Slide Table**


### Low Thrust with High Rigidity Type RoHS

## 25A-MXQ\(\subseteq\) Series

Ø6, Ø8, Ø12, Ø16, Ø20

### **How to Order**





- \*1 Not available, as the standard model has piping ports and auto switch mounting grooves on both sides. Please use the standard type.
- \* The operating speed range of the strokes marked with an asterisk (\*) is 50 to 300 mm/s. (Without stroke adjuster)

### 4 Adjuster options

_		•					
Symbol	Adjuster typ			type* <sup>3</sup>	Adjuster mountin		
					Extension stroke end	Retraction stroke end	
Z	Wit	hout adjuster					
ZA					•	•	
ZB	Ме	tal stopper with bum	per		•		
ZC						•	
ZD					•	•	
ZE	Rul	bber stopper			•		
ZF						•	
ZG					•	•	
ZH	Sho	ock absorber/RJ			•		
ZJ						•	
ZK					•	•	
ZL	Me	tal stopper			•		
ZM						•	
ZN				Without adjuster	/		
ZP	Ch/	orter total		Rubber stopper		•	
ZQ		gth type*2		Shock absorber/RJ		•	
ZS		9 1, p 0	ē	Metal stopper with bumper	] /	•	
ZT			nst	Metal stopper	/	•	
ZBF		Metal stopper with	adj	Rubber stopper	•	•	
ZBJ	ste	bumper	2	Shock absorber/RJ	•	•	
ZBM	adjuster		9	Metal stopper	•	•	
ZEC	ă		8	Metal stopper with bumper	•	•	
ZEJ	end	Rubber stopper	Retraction stroke end adjuster	Shock absorber/RJ	•	•	
ZEM	<u>\$</u>		lion	Metal stopper	•	•	
ZHC	stro		act	Metal stopper with bumper	•	•	
ZHF	n s	Shock absorber/RJ	3etı	Rubber stopper	•	•	
ZHM	ısic		_  ՟՟	Metal stopper	•	•	
ZLC	I +=	Metal stopper with bumper	•	•			
ZLF		Metal stopper		Rubber stopper	•	•	
ZLJ				Shock absorber/RJ			

### 6 Auto switch

Nil Without auto switch (Built-in magnet)

 For applicable auto switches, refer to page 207.

### 6 Number of auto switches

Nil	2
S	1
n	n

- 1 •: Shipped together with the product, but not assembled Without any symbol for the adjuster mounting position: The adjuster can be mounted afterward.
- \*2 Extension stroke end adjuster mounting holes have been removed to reduce the total length of the table.
- \*3 The metal stopper with bumper option is not available for Ø6.

### **Adjuster Mounting Position**



When the buffer mechanism or the end lock mechanism functional options are used, dust particles may be generated by the buffer part as well as the end lock part.
 The 25A- series specifications and dimensions are the same as those of the standard model.


### **Air Slide Table** Single Side-ported Type



## 5A-MXQ C Series

ø8, ø12

### **How to Order**





0	2 Bod	8				
Bore size	Standard type C	Symmetric type CL	Standard stroke [mm]			
8	Port Switch mounting groove	Switch mounting groove Port	10, 20, 30, 40, 50, 75			
12			10, 20, 30, 40, 50, 75, 100			

	Functional options						
Symbol	Functional option						
Nil	Without functional option						
1	With buffer						

0,	i anonona opnon
Nil	Without functional option
1	With buffer
2	With end lock
3	Axial piping
4	With buffer, end lock
5	With buffer, axial piping

### 6 Auto switch

Nil	Without auto switch (Built-in magnet)
* For ap	pplicable auto switches, refer to
page	207.

### Number of auto switches

Nil	2
S	1
n	n

### 4 Adjuster options/Functional option combinations

						Adjuster mounting Functional option combination								
		Adjuster type			position*1		Nil	1	2	3	4	5		
Symbol					Extension stroke end	Retraction stroke end	Without functional option	*2*6 With buffer	With end lock		With buffer,			
Z	W	ithout adjuste	r				0	0	0	0	0	0		
ZA					•	•	0	×	×	0	×	×		
ZB	Me	etal stopper v	vith	bumper	•		0	×	0	0	×	×		
ZC						•	0	×	×	0	×	×		
ZD					•	•	0	×	×	0	×	×		
ZE	Rι	ıbber stoppeı	•		•		0	0	0	0	0	0		
ZF		Shock absorber/RJ  Metal stopper				•	0	×	×	0	×	×		
ZG						•	0	×	×	0	×	×		
ZH	Sr						0	×	0	0	×	×		
ZJ						•	0	×	×	0	×	×		
ZK						•	0	×	×	0	×	×		
ZL	Me						0	0	0	0	0	0		
ZM						•	0	×	×	0	×	×		
ZN				Without adjuster	] /		0	○*4	×	0	×	0*		
ZP	Qh	orter overall		Rubber stopper	] /	•	0	×	×	0	×	×		
ZQ	_	gth type*3		Shock absorber/RJ	] /	•	0	×	×	0	×	×		
ZS	lien	girtype	te	Metal stopper with bumper	] /	•	0	×	×	0	×	×		
ZT			adjuster	Metal stopper	/	•	0	×	×	0	×	×		
'BF	<u></u>	Metal		Rubber stopper	•	•	0	×	×	0	×	×		
ZBJ	ste	stopper with	end	Shock absorber/RJ	•	•	0	×	×	0	×	×		
'BM	adjuster	bumper	(e)	Metal stopper	•	•	0	×	×	0	×	×		
ZEC	a	Rubber	stroke	Metal stopper with bumper	•	•	0	×	×	0	×	×		
ZEJ	end	stopper	st	Shock absorber/RJ	•	•	0	×	×	0	×	×		
EM	ê	Gropper	le le	Metal stopper	•	•	0	×	×	0	×	×		
HC	stroke	Shock	S.	Metal stopper with bumper		•	0	×	×	0	×	×		
'HF		absorber/RJ		Rubber stopper	•	•	0	×	×	0	×	×		
HM	Extension	absorber/110	æ	Metal stopper	•	•	0	×	×	0	×	×		
ZLC	en en	Metal		Metal stopper with bumper	•	•	0	×	×	0	×	×		
ZLF	Ĭ	stopper		Rubber stopper	•	•	0	×	×	0	×	×		
ZLJ		srobbei		Shock absorber/RJ	•	•	0	×	×	0	×	×		

- Shipped together with the product, but not assembled Without any symbol for the adjuster mounting position: The adjuster can be mounted afterward.
- 2 For the buffer mechanism, the buffer stroke will be shorter for the stroke that is adjusted by the extension stroke end adjuster.
- 3 Extension stroke end adjuster mounting holes have been removed to reduce the total length of the table.
- 4 The shorter total length type can be used, but a retraction stroke end adjuster cannot be mounted afterward.
- 5 There is no piping port on the side surface of the product.
- 6 As there is no magnet in the buffer mechanism, auto switches cannot be used on the buffer part.

#### Adjuster Mounting Position



- When the shock absorber, metal stopper with bumper, or adjuster option with metal stopper is used, metal-to-metal collisions occur, and may generate dust particles
- When the buffer mechanism or the end lock mechanism functional options are used, dust particles may be generated by the buffer part as well as the end lock part.

\* The 25A- series specifications and dimensions are the same as those of the standard model.



25A-MXQ Series Ø6, Ø8, Ø12, Ø16, Ø20, Ø25

**How to Order** 

**Height Interchangeable Type** 

25A-MXQ 12 Series compatible with secondary batteries

Air Slide Table



0	2 Bod	y option					
Bore	Standard type	Symmetric type	Standard stroke [mm]				
size	Nil	L					
6	Port Switch mounting groove	Switch mounting groove Port	10, 20, 30, 40, 50				
8			10, 20, 30, 40, 50, 75				
12	• <del>EPTA</del> S•		10, 20, 30, 40, 50, 75, 100				
16	Switch mounting groove Switch mounting groove		10, 20, 30, 40, 50, 75, 100, 125				
20		*1	10, 20, 30, 40, 50, 75, 100, 125, 150				
25	Port Port		10, 20, 30, 40, 50, 75, 100, 125, 150*				

5 Functional options

Symbol	Functional option
Nil	Without functional option
1	With buffer
2	With end lock
3	Axial piping
4	With buffer, end lock
5	With buffer, axial piping
	• • •

Number of auto switches Nil 2 S

**RoHS** 

6 Auto switch

Nil Without auto switch (Built-in magnet)

For applicable auto switches, refer to page 207.


Not available, as the standard model has piping ports and auto switch mounting grooves on both sides. Please use the standard type The operating speed range of the stroke marked with an asterisk (\*) is 50 to 300 mm/s. (Without stroke adjuster)

4 Adjuster options/Functional option combinations

					Adjuster mounting Functional option combination									
						ion*1	Nil	1	2	3	4	5		
Symbol		Ad	just	er type* <sup>6</sup>	Extension stroke end	Retraction stroke end	Without functional option	*2*7 With buffer	With end lock	Axial piping	*2*7 With buffer, end lock	*2*5*7 With buffer, axial piping		
Z	W	ithout adjuste	r				0	0	0	0	0	0		
ZA					•	•	0	×	×	0	×	×		
ZB	Me	etal stopper w	/ith	bumper	•		0	×	0	0	×	×		
ZC						•	0	×	×	0	×	×		
ZD					•	•	0	×	×	0	×	×		
ZE	Rι	ubber stopper			•		0	0	0	0	0	0		
ZF						•	0	×	×	0	×	×		
ZG					•	•	0	×	×	0	×	×		
ZH	Shock absorber/RJ						0	×	0	0	×	×		
ZJ						•	0	×	×	0	×	×		
ZK		Metal stopper				•	0	×	×	0	×	×		
ZL	Me						0	0	0	0	0	0		
ZM		••				•	0	×	×	0	×	×		
ZN				Without adjuster			0	○*4	×	0	×	O*4		
ZP	را			Rubber stopper		•	0	×	×	0	×	×		
ZQ	_	norter total		Shock absorber/RJ	] /	•	0	×	×	0	×	×		
ZS	ler	igin type"	ter	Metal stopper with bumper	] /	•	0	×	×	0	×	×		
ZT			adjuster	Metal stopper	/	•	0	×	×	0	×	×		
ZBF	_	Metal	adj	Rubber stopper	•	•	0	×	×	0	×	×		
ZBJ	adjuster	stopper with	end	Shock absorber/RJ	•	•	0	×	×	0	×	×		
ZBM	믉	bumper		Metal stopper	•	•	0	×	×	0	×	×		
ZEC		Rubber	stroke	Metal stopper with bumper	•	•	0	×	×	0	×	×		
ZEJ	end		stro	Shock absorber/RJ	•	•	0	×	×	0	×	×		
ZEM	e	stopper		Metal stopper	•	•	0	×	×	0	×	×		
ZHC	stroke	Chask	∣∺ું	Metal stopper with bumper	•	•	0	×	×	0	×	×		
ZHF		Shock	Retraction	Rubber stopper	•	•	0	×	×	0	×	×		
ZHM	Extension	absorber/RJ	Re	Metal stopper	•	•	0	×	×	0	×	×		
ZLC	Su		]	Metal stopper with bumper	•	•	0	×	×	0	×	×		
ZLF	꽃	Metal		Rubber stopper	•	•	0	×	×	0	×	×		
ZLJ	ш	யி stopper		Shock absorber/RJ	•	•	0	×	×	0	×	×		

- •: Shipped together with the product, but not assembled Without any symbol for the adjuster mounting position: The adjuster can be mounted afterward.
- For the buffer mechanism, the buffer stroke will be shorter for the stroke that is adjusted by the extension stroke end adjuster.
- Extension stroke end adjuster mounting holes have been removed to reduce the total length of the table.
- The shorter total length type can be used, but a retraction stroke end adjuster cannot be mounted afterward.
- There is no piping port on the side surface of the product.
- The metal stopper with bumper option is not available for ø6.
- As there is no magnet in the buffer mechanism, auto switches cannot be used on the buffer part.

**Adjuster Mounting Position** 



- When the shock absorber, metal stopper with bumper, or adjuster option with metal stopper is used, metal-to-metal collisions occur, and may generate dust particles.
- When the buffer mechanism or the end lock mechanism functional options are used, dust particles may be generated by the buffer part as well as the end lock part.
- \* The 25A- series specifications and dimensions are the same as those of the standard model.

Click here for details.

Control Valves

Air Cylinders

Related Products

Rotary Actuators


Air Grippers Equipment Vacuum


Air Preparation

Clean Air Filters

Switches

# Air Slide Table **25A-MXQ Series** Ø6, Ø8, Ø12, Ø16, Ø20, Ø25






\* The 25A- series specifications and dimensions are the same as those of the standard model.

With shock absorber is not available in the 25A-MXQ6 series.
 When the adjuster option with shock absorber or metal stopper is used, metal-to-metal collisions occur, and

may generate dust particles.

### **Air Slide Table** 25A-MXW Series Ø8, Ø12, Ø16, Ø20, Ø25



\* The 25A- series specifications and dimensions are the same as those of the standard model.


Click here for details.

Air Cylinders Control Valves

Auto Switches

# Air Slide Table **25A-IVXP** Series Ø6, Ø8, Ø10, Ø12, Ø16

RoHS



\* The 25A- series specifications and dimensions are the same as those of the standard model.



<sup>\*</sup> Adjuster for 25A-MXP6 series is available for one side only.

st Shock absorber is not available in 25A-MXP6 and 25A-MXP8 series.

<sup>\*</sup> When the adjuster option with shock absorber or metal stopper is used, metal-to-metal collisions occur, and may generate dust particles.